




!
FREQUENT
COMPONENTS
ON PAGE 248



AVAILABLE COLOURS

RAL 9010	7035	1013






HOOD

PAGE 254

HO

N°					
1		3XL150HP 3XL175HP 3XL200HP 3XL225HP 3XL250HP	MAIN ARM braccio hercules hercules arm Gelenkarm Hercules bras hercules brazo hercules braço hercules	150 cm 175 cm 200 cm 225 cm 250 cm	1 CP

N° 


2		3XL922/D	staffa bramante con disco bramante bracket with disk Halter Bramante mit Scheibe support bramante avec disque soporte bramante con disco estribo bramante com disco		1 CP	
3		ESTRTLUXL4000 ESTRTLUXL5000 ESTRTLUXL6000 ESTRTLUXL7000	terminale leggero lux light lux terminal bar leichtes Ausfallprofil Lux barre de charge légère lux barra de carga ligera lux barra terminal leve lux		400 cm 500 cm 600 cm 700 cm	1 PZ 
4		939TLL	tappo PVC terminale leggero lux light terminal bar PVC cap PVC-Deckel für schweren Ende-Ausfallprofil Lux bouchon PVC barre de charge légère lux tapa PVC para barra de carga ligera lux tampa PVC barra terminal leve lux		1 CP	
5		PFARG11/1	arganello 11/1 reduction winch 11/1 Wunsch 11/1 treuil 11/1 máquina sinfín 11/1 sarilho 11/1		1 PZ	
6		3XL929	perno raccoglibraccio arm folding checkpin Armhalterung mit Stift pivot ramassage petit bras perno raccoglibrazo eixo recolhe braço		1 PZ	